DERYA®

CARINA U.S.8

USER MANUAL

"THANK YOU FOR CHOOSING A DERYA ARMS PRODUCT"

THIS BOOKLET WILL GUIDE YOU THROUGH HANDLING YOUR FIREARM SAFELY

PLEASE NOTE: CHANGES MAY BE MADE WITHOUT NOTICE

Your shotgun features an innovative and unique design. With regular care and cleaning, your firearm will serve you for a life time. The firearm was manufactured by DERYA ARMS from high quality raw materials and with high-tech CNC machines in our factory.

Please read and understand all the directions and instructions in this Manual to guarantee the best performance and a safe shooting experience. Maintain your firearm properly in accordance with these instructions so it will remain safe, and performs properly.

Always remember that you are using a firearm; always follow all safety rules and be aware that it is your responsibility to share your knowledge, and educate others in the safe use of this firearm.

Before firing a cartridge, learn the parts of your firearm and understand how it operates. Please read this manual carefully and enjoy your firearm safely.

MAINTENANCE INSTRUCTIONS:

1) NEVER MAKE CHANGES OR ALTERATIONS TO YOUR SHOTGUN

This shotgun was built to a proven and tested design, and manufactured with care. It must NEVER be altered or changed. Changing or altering any part of your shotgun may result in serious injuries to you or others, and is NOT RECOMMENDED by the manufacturer. Any changes made to the shotgun or use of non-factory parts voids the factory warranty.

2) PROPER CARE AND STORAGE

Regular care and cleaning of your firearm is key to its proper functionality and reliability. ALWAYS make sure that the firearm is UNLOADED before you leave the range and check it again before you start the cleaning process.

THE RESPONSIBILITIES OF THE USER

The laws of your country give you the right to possess a hunting firearm. Appreciate and enjoy your rights with care. Be aware that, as an owner of a firearm, you are responsible for ensuring your own safety and that of your shooting partners, observers, and the environment.

DISCLAIMER

This firearm is sold with the understanding that the buyer will obey all applicable domestic laws, therefore Derya Arms is not responsible for death or injuries caused by incorrect or irresponsible use.

DERYA ARMS DOES NOT ACCEPT ANY RESPONSIBILITIES FOR DAMAGE DUE TO THE FOLLOWING CAUSES

1) INCORRECT OR IRRESPONSIBLE USE OF THE FIREARM
2) USE OF INCORRECT GAUGE AMMUNITION OR RELOADED, DAMAGED OR INPROPER CARTRIDGES
3) INSUFFICIENT AND/OR INCORRECT MAINTENANCE OR CLEANING WHICH CAUSES TO DAMAGE OR WEAR
4) SALE CONTRARY TO APPLICABLE LAWS AND REGULATIONS
5) CHANGING OR CONVERSION OF THE FIREARM'S ORIGINAL DESIGN, OPERATING MECHANISM, ACCESSORIES, MAGAZINES OR MECHANICALS
6) CARELESS, DANGEROUS OR CRIMINAL USE
7) USING THE FIREARM WITHOUT FIRST READING, UNDERSTANDING AND FOLLOWING ALL SAFETY RULES
8) ANY OTHER USE OR ACTION THAT IS BEYOND THE DIRECT CONTROL OF THE MANUFACTURER

IMPORTANT WARNING

1) Read the instructions booklet completely before using your firearm.
2) Always be aware of the handling and functional characteristics of your firearms.
3) Always unload your firearm when not in use (remove all cartridges).

When stored or not in use, firearms should always be unloaded and move the safety lever to the WHITE position to block the trigger of your firearm.

Always remove all cartridges and inspect the chamber to ensure your firearm is unloaded.
1) After shooting.
2) Before racking or after picking up the firearm.
3) Before putting the gun into its case.
4) Any time you are not using your firearm.
5) Before handing your gun to anyone else.
4) ALWAYS KEEP YOUR FIREARM POINTED IN A SAFE DIRECTION. This ensures you do not injure yourself or anyone else.
5) ALWAYS STORE YOUR FIREARM OUT OF REACH OF CHILDREN OR OTHER UNAUTHORIZED PEOPLE. There are many ways of keeping your firearms locked and stored safely and securely. Always secure your firearm in accordance with applicable laws in your area and always unload and then lock the firearm when not in use or whenever it will be unattended.

6) ALWAYS OBEY ALL LAWS REGARDING OWNERSHIP, TRANSPORT, AND SHOOTING YOUR FIREARM. Never point your firearm at a person. Do not harm any person or damage any public property.

7) IF YOUR FIREARM DOES NOT FIRE AFTER PULLING THE TRIGGER: STOP, WAIT A MINUTE, AND USE EXTRA CAUTION WHEN OPENING THE BOLT. If your firearm did not fire after pulling the trigger STOP! Keep the firearm pointed in a safe direction, apply the safety by moving the safety lever to the white position. Wait 60 seconds. Carefully open the bolt by pulling the cocking handle and eject the shell in a safe direction. Always remember when you experience a misfire, your firearm is still loaded and could fire at any time (a "hang fire").

8) ALWAYS TREAT YOUR FIREARM AS IF IT IS LOADED, EVEN WHEN THE SAFETY IS ON. Always keep your finger away from the trigger unless you are on target and prepared to shoot. Never forget that even with safety ON, you are responsible for the direction your firearm is pointing. Do not count on a mechanical device.

9) This firearm was produced under the control and supervision of Derya Arms. The firearm must never be altered. Derya does not recommended the use of any spare parts or accessories and magazines other than those included in the original box or received from Derya. If you need magazines, spare parts or repair, contact our authorized distributor in your country or Derya Arms ONLY.

10) ENSURE THE BARREL IS NOT PLUGGED OR OBSTRUCTED BEFORE YOU LOAD YOUR GUN. The barrel should not have any residue from bore cleaning solvent or oil, or any other foreign material inside the bore, chamber or choke. If the barrel is blocked or otherwise obstructed, even partially, this may cause bulging and/or a breech explosion and/or a split barrel. If you feel a strange recoil or the report sounds unusually loud or soft STOP SHOOTING IMMEDIATELY and check the barrel for obstructions and bulges.

NEVER try to clear an obstruction in your barrel by firing another shell!

ANY PARTIAL OR COMPLETE BORE OBSTRUCTION can cause serious injury or death to the shooter or bystanders.

SERIAL NUMBER

The serial number is engraved on the firearm on several places. Every firearm has a unique number. This number is used for legal and warranty matters. Derya suggests that owners note and store the serial numbers of all of your firearms in a secure location away from the firearms.

DISASSEMBLY OF THE FIREARM

1) Push the release latch and cock the firearm by pulling the forend.

2) Unscrew the heat cage screws by using an allen wrench.

3) Unscrew the heat cage top screw by using an allen wrench.

4) Unscrew the magazine cap by turning in arrow direction.

5) Unscrew the magazine band retainer screw by using an allen wrench.

6) Pull the barrel in arrow direction.














SETTINGS

1) Push the safety button to SAFE position.

2) Load cardridges into the tube until it reaches it's capacity.

3) Cock the firearm by pulling the forend.







BASIC PARTS

P.NO	PART NAME
1	Barrel
2	Ball Spring
3	Ball
4	Heat Cage Screw
5	Heat Cage
6	Bottom Extractor Pin
7	Bottom Extractor
8	Bottom Extractor Spring
9	Lock
10	Top Extractor
11	Top Extractor Pin
12	Top Extractor
13	Firing Pin Retaining Pin
14	Bottom Extractor Rivet
15	Firing Pin
16	Shell Stop Right
17	Shell Stop Right Pin
18	Receiver
19	Shell Stop Spring
20	Shell Stop Left
21	Shell Stop Left Pin
22	Carrier
23	Carrier Screw
24	Carrier Screw Conta
25	Buttstock


P.NO	PART NAME
26	Buttstock Connection Screw
27	Buttstock Connection Washer
28	Recoil Pad
29	Recoil Pad Screw
30	Stud Swivel
31	Sling Swivel
32	Hammer Spring
33	Hammer Spring Cap
34	Hammer Spring Socket
35	Safety Spring
36	Safety Pin
37	Trigger
38	Trigger Spring
39	Hammer Back Pin
40	Safety
41	Trigger Guard Screw
42	Trigger Pin
43	Hammer Pin
44	Trigger Guard
45	Hammer Stirrup Pin
46	Hammer
47	Hammer Stirrup
48	Bolt Catch Spring
49	Bolt Catch Spring Pin
50	Bolt Catch

P.NO	PART NAME
51	Bolt Catch Pin
52	Magazine Plug
53	Magazine Tube
54	Magazine Spring
55	Magazine Tube Front Plug
56	Forend Tube
57	Bolt
58	Slide Carrier Spring
59	Slide Carrier Pin
60	Slide Carrier Pin Retainer
61	Slide Carrier
62	Forend Retaining Nut Upper
63	Forend
64	Forend Retaining Nut Lower
65	Magazine Band
66	Magazine Cap
67	Magazine Band Screw
68	Sling Swivel Pin

Note: Some models will vary from exploded view.

DERYA®

EXPLODED VİEW



05/2022

Derya Silah San.Ltd.
O.S.B. 41959 Sk.
No:24/1 42700
Konya/Turkey

+90 332 514 8118

support@deryaarms.com

www.deryaarms.com