DERYA®

LEVER ACTION
USER MANUAL

"THANK YOU FOR CHOOSING A DERYA ARMS PRODUCT"

THIS BOOKLET WILL GUIDE YOU THROUGH HANDLING YOUR FIREARM SAFELY

PLEASE NOTE: CHANGES MAY BE MADE WITHOUT NOTICE

Your shotgun features an innovative and unique design. With regular care and cleaning, your firearm will serve you for a life time. The firearm was manufactured by DERYA ARMS from high quality raw materials and with high-tech CNC machines in our factory.

Please read and understand all the directions and instructions in this Manual to guarantee the best performance and a safe shooting experience. Maintain your firearm properly in accordance with these instructions so it will remain safe, and performs properly.

Always remember that you are using a firearm; always follow all safety rules and be aware that it is your responsibility to share your knowledge, and educate others in the safe use of this firearm.

Before firing a cartridge, learn the parts of your firearm and understand how it operates. Please read this manual carefully and enjoy your firearm safely.

MAINTENANCE INSTRUCTIONS:

1) NEVER MAKE CHANGES OR ALTERATIONS TO YOUR SHOTGUN

This shotgun was built to a proven and tested design, and manufactured with care. It must NEVER be altered or changed. Changing or altering any part of your shotgun may result in serious injuries to you or others, and is NOT RECOMMENDED by the manufacturer. Any changes made to the shotgun or use of non-factory parts voids the factory warranty.

2) PROPER CARE AND STORAGE

Regular care and cleaning of your firearm is key to its proper functionality and reliability. ALWAYS make sure that the firearm is UNLOADED before you leave the range and check it again before you start the cleaning process.

THE RESPONSIBILITIES OF THE USER

The laws of your country give you the right to possess a hunting firearm. Appreciate and enjoy your rights with care. Be aware that, as an owner of a firearm, you are responsible for ensuring your own safety and that of your shooting partners, observers, and the environment.

DISCLAIMER

This firearm is sold with the understanding that the buyer will obey all applicable domestic laws, therefore Derya Arms is not responsible for death or injuries caused by incorrect or irresponsible use.

DERYA ARMS DOES NOT ACCEPT ANY RESPONSIBILITIES FOR DAMAGE DUE TO THE FOLLOWING CAUSES

1) INCORRECT OR IRRESPONSIBLE USE OF THE FIREARM
2) USE OF INCORRECT GAUGE AMMUNITION OR RELOADED, DAMAGED OR INPROPER CARTRIDGES
3) INSUFFICIENT AND/OR INCORRECT MAINTENANCE OR CLEANING WHICH CAUSES TO DAMAGE OR WEAR
4) SALE CONTRARY TO APPLICABLE LAWS AND REGULATIONS
5) CHANGING OR CONVERSION OF THE FIREARM'S ORIGINAL DESIGN, OPERATING MECHANISM, ACCESSORIES, MAGAZINES OR MECHANICALS
6) CARELESS, DANGEROUS OR CRIMINAL USE
7) USING THE FIREARM WITHOUT FIRST READING, UNDERSTANDING AND FOLLOWING ALL SAFETY RULES
8) ANY OTHER USE OR ACTION THAT IS BEYOND THE DIRECT CONTROL OF THE MANUFACTURER

IMPORTANT WARNING

1) Read the instructions booklet completely before using your firearm.
2) Always be aware of the handling and functional characteristics of your firearms.
3) Always unload your firearm when not in use (remove all cartridges).

When stored or not in use, firearms should always be unloaded and move the safety lever to the WHITE position to block the trigger of your firearm.

Always remove all cartridges and inspect the chamber to ensure your firearm is unloaded.
1) After shooting.
2) Before racking or after picking up the firearm.
3) Before putting the gun into its case.
4) Any time you are not using your firearm.
5) Before handing your gun to anyone else.
4) ALWAYS KEEP YOUR FIREARM POINTED IN A SAFE DIRECTION. This ensures you do not injure yourself or anyone else.
5) ALWAYS STORE YOUR FIREARM OUT OF REACH OF CHILDREN OR OTHER UNAUTHORIZED PEOPLE. There are many ways of keeping your firearms locked and stored safely and securely. Always secure your firearm in accordance with applicable laws in your area and always unload and then lock the firearm when not in use or whenever it will be unattended.

6) ALWAYS OBEY ALL LAWS REGARDING OWNERSHIP, TRANSPORT, AND SHOOTING YOUR FIREARM. Never point your firearm at a person. Do not harm any person or damage any public property.

7) IF YOUR FIREARM DOES NOT FIRE AFTER PULLING THE TRIGGER: STOP, WAIT A MINUTE, AND USE EXTRA CAUTION WHEN OPENING THE BOLT. If your firearm did not fire after pulling the trigger STOP! Keep the firearm pointed in a safe direction, apply the safety by moving the safety lever to the white position. Wait 60 seconds. Carefully open the bolt by pulling the cocking handle and eject the shell in a safe direction. Always remember when you experience a misfire, your firearm is still loaded and could fire at any time (a "hang fire").

8) ALWAYS TREAT YOUR FIREARM AS IF IT IS LOADED, EVEN WHEN THE SAFETY IS ON. Always keep your finger away from the trigger unless you are on target and prepared to shoot. Never forget that even with safety ON, you are responsible for the direction your firearm is pointing. Do not count on a mechanical device.

9) This firearm was produced under the control and supervision of Derya Arms. The firearm must never be altered. Derya does not recommended the use of any spare parts or accessories and magazines other than those included in the original box or received from Derya. If you need magazines, spare parts or repair, contact our authorized distributor in your country or Derya Arms ONLY.

10) ENSURE THE BARREL IS NOT PLUGGED OR OBSTRUCTED BEFORE YOU LOAD YOUR GUN. The barrel should not have any residue from bore cleaning solvent or oil, or any other foreign material inside the bore, chamber or choke. If the barrel is blocked or otherwise obstructed, even partially, this may cause bulging and/or a breech explosion and/or a split barrel. If you feel a strange recoil or the report sounds unusually loud or soft STOP SHOOTING IMMEDIATELY and check the barrel for obstructions and bulges.

NEVER try to clear an obstruction in your barrel by firing another shell!

ANY PARTIAL OR COMPLETE BORE OBSTRUCTION can cause serious injury or death to the shooter or bystanders.

SERIAL NUMBER

The serial number is engraved on the firearm on several places. Every firearm has a unique number. This number is used for legal and warranty matters. Derya suggests that owners note and store the serial numbers of all of your firearms in a secure location away from the firearms.

LOADING THE FIREARM

1) Insert proper cartridges in to the magazine tube by pushing to the loading cap.

2) Push the last round with the little finger.

3) Pull the lever down, this action forces the firing pin and bolt backwards and a cartridge will lift up into the chamber.

4) Close the lever.









UNLOADING THE FIREARM

1) Pull the lever down, If there's an empty cartridge in the chamber, it will eject.



SAFETY SYSTEM

1) When the lever is pulled down, the safety is in position.

2) If the lever isn't closed completely the safety will be on.





3) When the lever is completely closed, the lever will push the safety and changes it to off position.

4) Pull the trigger and drop the hammer slowly by keeping it with your thumb finger. (Release the trigger by taking the finger completely off of it as the hammer beginning to be lowered)






Drip an oil to the trigger system as shown.
Lubricate the Slide from both sides.
Clean and lubricate the slide channels.
Clean the bore of the barrel by using a cleaning rod.
Clean and lubricate the loading cap.
Lubricate the carrier and trigger guard plate
Synthetic version

BASIC PARTS

P.NO	PART NAME
1	Barrel Assembly[1]
2	Front Sight
3	Front Sight Screw
4	Back Sight
5	Back Sight Screw
6	Back Sight Pin
7	Back Sight Spring
8	Screw Cap
9	Bolt
10	Hammer Screw
11	Hammer
12	Hammer Plate
13	Hammer Spring
14	Hammer Spring Cap
15	Stock w/ Recoil Pad
16	Trigger Guard
17	Carrier
18	Carrier Retaining Screw
19	Lever
20	Lever Pin
21	Forend
22	Magazine Tube
23	Magazine Tube Spring
24	Front Plug
25	Back Plug

P.NO	PART NAME
26	Cap Screw
27	Cap
28	Right Feed Lever
29	Left Feed Lever
30	Carrier Spring
31	Carrier Spring Screw


P.NO	PART NAME (Synthetic version)
32	Stock
33	Cheekpad
34	Cheekpad Nut
35	Cheekpad Screw
36	Recoil Pad Extension
37	Recoil Pad
38	Sling Swivel
39	Recoil Pad Screw

Note:
Some models will vary from exploded view.

[1]Barrel, Receiver and Picatinny Rail

DERYA

EXPLODED VIEW



NOTES

Warranty Certificate

Derya warranty covers its firearms and parts. We offer 2 years Warranty on our products for their intended purpose. As with any product, abuse, gunsmithing by an unqualified person and normal wear and tear are excluded. Additionally, if the firearm was modified and/or repaired by an unqualified gunsmith without permission from DERYA®, the warranty will be void.

DERYA® warrants that the enclosed firearm was originally manufactured free of defects in material, workmanship and mechanical function. DERYA® agrees to correct any defect in the firearm for the original purchaser/importer by repair, adjustment or replacement, at DERYA's® option, with the same or comparable quality components (or by replacing the firearms at DERYA's® option); provided, however, that the firearm is returned unloaded and the freight prepaid.

This warranty is null and void if the firearm has been misused, damaged (by accident or otherwise), fired with hand loaded, reloaded or improper ammunition, fired with an obstruction in the barrel, damaged through failure to provide reasonable and necessary maintenance as described in the manual accompanying the firearm, or if unauthorized repair or any alteration, including of a cosmetic nature, has been performed on the firearm.

Subject to the foregoing, this warranty confers the right to have the covered firearm or its parts repaired, adjusted or replaced exclusively upon the original purchaser, which right is not transferable to any other person. No implied warranties of any kind are made herein and this warranty does not apply to any accessory items attached or appurtenant to the firearm.

In no event shall DERYA® be liable for any incidental or consequential damages arising from or in connection with this warranty, In the event warranty service is needed, contact the dealer you purchased the firearm from; or the importer/distributor of your country; or DERYA® customer service by mailing to support@deryaarms.com.

08/2022

Derya Silah San.Ltd.
O.S.B. 41959 Sk.
No:24/1 42700
Konya/Turkey

+90 332 514 8118

support@deryaarms.com

www.deryaarms.com