DERYA®

TM22 LEVER ACTION
USER MANUAL

"THANK YOU FOR CHOOSING A DERYA ARMS PRODUCT"

THIS BOOKLET WILL GUIDE YOU THROUGH HANDLING YOUR FIREARM SAFELY

PLEASE NOTE: CHANGES MAY BE MADE WITHOUT NOTICE

Your rifle features an innovative and unique design. With regular care and cleaning, your firearm will serve you for a life time. The firearm was manufactured by DERYA ARMS from high quality raw materials and with high-tech CNC machines in our factory.

Please read and understand all the directions and instructions in this manual to guarantee the best performance and a safe shooting experience. Maintain your firearm properly in accordance with these instructions so it will remain safe, and performs properly.

Always remember that you are using a firearm; always follow all safety rules and be aware that it is your responsibility to share your knowledge, and educate others in the safe use of this firearm.

Before firing a cartridge, learn the parts of your firearm and understand how it operates. Please read this manual carefully and enjoy your firearm safely.

MAINTENANCE INSTRUCTIONS:

1) NEVER MAKE CHANGES OR ALTERATIONS TO YOUR RIFLE

This rifle was built to a proven and tested design, and manufactured with care. It must NEVER be altered or changed. Changing or altering any part of your rifle may result in serious injuries to you or others, and is NOT RECOMMENDED by the manufacturer. Any changes made to the rifle or use of non-factory parts voids the factory warranty.

2) PROPER CARE AND STORAGE

Regular care and cleaning of your firearm is key to its proper functionality and reliability. ALWAYS make sure that the firearm is UNLOADED before you leave the range and check it again before you start the cleaning process.

THE RESPONSIBILITIES OF THE USER

The laws of your country give you the right to possess a hunting firearm. Appreciate and enjoy your rights with care. Be aware that, as an owner of a firearm, you are responsible for ensuring your own safety and that of your shooting partners, observers, and the environment.

DERYA

DISCLAIMER

This firearm is sold with the understanding that the buyer will obey all applicable domestic laws, therefore Derya Arms is not responsible for death or injuries caused by incorrect or irresponsible use.



DERYA ARMS DOES NOT ACCEPT ANY RESPONSIBILITIES FOR DAMAGE DUE TO THE FOLLOWING CAUSES

1) INCORRECT OR IRRESPONSIBLE USE OF THE FIREARM
2) USE OF INCORRECT GAUGE AMMUNITION OR RELOADED, DAMAGED OR INPROPER CARTRIDGES
3) INSUFFICIENT AND/OR INCORRECT MAINTENANCE OR CLEANING WHICH CAUSES TO DAMAGE OR WEAR
4) SALE CONTRARY TO APPLICABLE LAWS AND REGULATIONS
5) CHANGING OR CONVERSION OF THE FIREARM'S ORIGINAL DESIGN, OPERATING MECHANISM, ACCESSORIES, MAGAZINES OR MECHANICALS
6) CARELESS, DANGEROUS OR CRIMINAL USE
7) USING THE FIREARM WITHOUT FIRST READING, UNDERSTANDING AND FOLLOWING ALL SAFETY RULES
8) ANY OTHER USE OR ACTION THAT IS BEYOND THE DIRECT CONTROL OF THE MANUFACTURER

IMPORTANT WARNING

1) Read the instructions booklet completely before using your firearm.
2) Always be aware of the handling and functional characteristics of your firearms.
3) Always unload your firearm when not in use (remove all cartridges).

When stored or not in use, firearms should always be unloaded and move the safety lever to the WHITE position to block the trigger of your firearm.

Always remove all cartridges and inspect the chamber to ensure your firearm is unloaded.
1) After shooting.
2) Before racking or after picking up the firearm.
3) Before putting the gun into its case.
4) Any time you are not using your firearm.
5) Before handing your gun to anyone else.
4) ALWAYS KEEP YOUR FIREARM POINTED IN A SAFE DIRECTION. This ensures you do not injure yourself or anyone else.
5) ALWAYS STORE YOUR FIREARM OUT OF REACH OF CHILDREN OR OTHER UNAUTHORIZED PEOPLE. There are many ways of keeping your firearms locked and stored safely and securely. Always secure your firearm in accordance with applicable laws in your area and always unload and then lock the firearm when not in use or whenever it will be unattended.

6) ALWAYS OBEY ALL LAWS REGARDING OWNERSHIP, TRANSPORT, AND SHOOTING YOUR FIREARM. Never point your firearm at a person. Do not harm any person or damage any public property.

7) IF YOUR FIREARM DOES NOT FIRE AFTER PULLING THE TRIGGER: STOP, WAIT A MINUTE, AND USE EXTRA CAUTION WHEN OPENING THE BOLT. If your firearm did not fire after pulling the trigger STOP! Keep the firearm pointed in a safe direction, apply the safety by moving the safety lever to the white position. Wait 60 seconds. Carefully open the bolt by pulling the cocking handle and eject the shell in a safe direction. Always remember when you experience a misfire, your firearm is still loaded and could fire at any time (a "hang fire").

8) ALWAYS TREAT YOUR FIREARM AS IF IT IS LOADED, EVEN WHEN THE SAFETY IS ON. Always keep your finger away from the trigger unless you are on target and prepared to shoot. Never forget that even with safety ON, you are responsible for the direction your firearm is pointing. Do not count on a mechanical device.

9) This firearm was produced under the control and supervision of Derya Arms. The firearm must never be altered. Derya does not recommended the use of any spare parts or accessories and magazines other than those included in the original box or received from Derya. If you need magazines, spare parts or repair, contact our authorized distributor in your country or Derya Arms ONLY.

10) ENSURE THE BARREL IS NOT PLUGGED OR OBSTRUCTED BEFORE YOU LOAD YOUR GUN. The barrel should not have any residue from bore cleaning solvent or oil, or any other foreign material inside the bore, chamber or choke. If the barrel is blocked or otherwise obstructed, even partially, this may cause bulging and/or a breech explosion and/or a split barrel. If you feel a strange recoil or the report sounds unusually loud or soft STOP SHOOTING IMMEDIATELY and check the barrel for obstructions and bulges.

NEVER try to clear an obstruction in your barrel by firing another shell!

ANY PARTIAL OR COMPLETE BORE OBSTRUCTION can cause serious injury or death to the shooter or bystanders.

SERIAL NUMBER

The serial number is engraved on the firearm on several places. Every firearm has a unique number. This number is used for legal and warranty matters. Derya suggests that owners note and store the serial numbers of all of your firearms in a secure location away from the firearms.

Model	TM22 LEVER ACTION
Caliber	.22LR
Action	Detachable Box Magazine Lever Action
Capacity	10 Rounds
Barrel Length	457mm / 18" - 500mm / 20"
Overall Length	914mm / 36" - 980mm / 38.5"
Overall Width	40mm / 1.57" - 57mm / 2.25"
Overall Height	120mm / 4.72" - 127mm / 5"
Front & Rear Sight	Front Sight & Picatinny Rail
Weight, Empty	2.4 kg / 5.3 lbs
Weight, Loaded	2.52 kg / 5.55 lbs
Finish	Matte (Parkerized Steel / Anodized Aluminum)
Stock	Walnut / Synthetic
Thread	½ x 28 UNEF

CALIBER



.22LR

LOADING THE FIREARM

1) Press down on the follower with the thumb of one hand, and then feed the round into the magazine, tuck each round under the feed lips and then move on.

2) Insert the fully loaded magazine into your rifle and ensure it properly engaged.

3) Pull the lever down, this action forces the firing pin and bolt backwards and a cartridge will lift up into the chamber.

4) Close the lever.









UNLOADING THE FIREARM

1) Pull the lever down, If there's an empty cartridge in the chamber, it will eject.

2) Press the magazine release button to remove the magazine from the rifle.





1) When the lever is pulled down, the safety is in position.

2) If the lever isn't closed completely the safety will be on.





3) When the lever is completely closed, the lever will push the safety and changes it to off position.

4) Pull the trigger and drop the hammer slowly by keeping it with your thumb finger. (Release the trigger by taking the finger completely off of it as the hammer beginning to be lowered)





BASIC PARTS

P.NO	PART NAME
1	Barrel with Receiver
2	Trigger
3	Trigger Pin
4	Trigger Housing
5	Disconnector Spring
6	Disconnector
7	Disconnector Pin
8	Trigger Housing Sleeve
9	Safety
10	Safety Spring Pin
11	Safety Spring
12	Sleeve Pin
13	Trigger Housing Pin
14	Lower Cap
15	Ejector
16	Ejector Pin
17	Magazine Release
18	Lever Plunger Pin
19	Lever Plunger Pin Spring
20	Lever Plunger Cap
21	Magazine Catch Spring
22	Magazine Catch Screw
23	Magazine Catch Assembling Screw
24	Magazine Release Button
25	Magazine Release Button Screw

P.NO	PART NAME
26	Lever
27	Bolt
28	Firing Pin Spring
29	Firing Pin
30	Firing Pin Retaining Pin
31	Extractor Spring
32	Extractor
33	Extractor Pin
34	Hammer Spring Cap
35	Hammer Spring
36	Hammer Spring
37	Hammer
38	Hammer Pin
39	Follower
40	Follower Screw
41	Reciever Pin
42	Screw Cap
43	Pivot Pin
44	Picatinny
45	Picatinny Screw
46	Rear Sight
47	Rear Sight Pin
48	Rear Sight Spring
49	Rear Sight Assembling Pin
50	Magazine Tube


P.NO	PART NAME
51	Synthetic Forend
52	Forend Cover
53	Forend Cover Pin
54	Forend Cover Screw
55	Barrel Band
56	Barrel Band Pin
57	Front Sight
58	Front Sight Screw
59	Barrel Nut
60	Stock
61	Cheekpad
62	Cheekpad Adjusting Screw Cap
63	Cheekpad Adjusting Screw
64	Cheekpad Adjusting Nut
65	Sling Swivel
66	Recoil Pad Extension
67	Recoil Pad
68	Recoil Pad Screw
69	Magazine
70	Magazine Follower
71	Magazine Spiring
72	Magazine Base Plate Retainer
73	Magazine Base Plate

P.NO	PART NAME
A1	Walnut Stock
A2	Recoil Pad
A3	Recoil Pad Screw
A4	Walnut Forend


Note:
Some models will vary from exploded view.

[1]Barrel, Receiver and Picatinny Rail

EXPLODED VIEW



CLEANING THE FIREARM



Warranty Certificate

Derya warranty covers its firearms and parts. We offer 2 years Warranty on our products for their intended purpose. As with any product, abuse, gunsmithing by an unqualified person and normal wear and tear are excluded. Additionally, if the firearm was modified and/or repaired by an unqualified gunsmith without permission from DERYA®, the warranty will be void.

DERYA® warrants that the enclosed firearm was originally manufactured free of defects in material, workmanship and mechanical function. DERYA® agrees to correct any defect in the firearm for the original purchaser/importer by repair, adjustment or replacement, at DERYA's® option, with the same or comparable quality components (or by replacing the firearms at DERYA's® option); provided, however, that the firearm is returned unloaded and the freight prepaid.

This warranty is null and void if the firearm has been misused, damaged (by accident or otherwise), fired with hand loaded, reloaded or improper ammunition, fired with an obstruction in the barrel, damaged through failure to provide reasonable and necessary maintenance as described in the manual accompanying the firearm, or if unauthorized repair or any alteration, including of a cosmetic nature, has been performed on the firearm.

Subject to the foregoing, this warranty confers the right to have the covered firearm or its parts repaired, adjusted or replaced exclusively upon the original purchaser, which right is not transferable to any other person. No implied warranties of any kind are made herein and this warranty does not apply to any accessory items attached or appurtenant to the firearm.

In no event shall DERYA® be liable for any incidental or consequential damages arising from or in connection with this warranty, In the event warranty service is needed, contact the dealer you purchased the firearm from; or the importer/distributor of your country; or DERYA® customer service by mailing to support@deryaarms.com.

09/2023

Derya Silah San.Ltd.
O.S.B. 41959 Sk.
No:24/1 42700
Konya/Turkey

+90 332 514 8118

support@deryaarms.com

www.deryaarms.com