DERYA®

MERIVA OVER & UNDER
USER MANUAL

ENJOY YOUR SHOTGUN

"THANK YOU FOR CHOOSING A DERYA ARMS PRODUCT"

THIS BOOKLET WILL GUIDE YOU THROUGH HANDLING YOUR FIREARM SAFELY

PLEASE NOTE: CHANGES MAY BE MADE WITHOUT NOTICE

Your shotgun features an innovative and unique design. With regular care and cleaning, your firearm will serve you for a life time. The firearm was manufactured by DERYA ARMS from high quality raw materials and with high-tech CNC machines in our factory.

Please read and understand all the directions and instructions in this Manual to guarantee the best performance and a safe shooting experience. Maintain your firearm properly in accordance with these instructions so it will remain safe, and performs properly.

Always remember that you are using a firearm; always follow all safety rules and be aware that it is your responsibility to share your knowledge, and educate others in the safe use of this firearm.

Before firing a cartridge, learn the parts of your firearm and understand how it operates. Please read this manual carefully and enjoy your firearm safely.

MAINTENANCE INSTRUCTIONS:

1) NEVER MAKE CHANGES OR ALTERATIONS TO YOUR SHOTGUN

This shotgun was built to a proven and tested design, and manufactured with care. It must NEVER be altered or changed. Changing or altering any part of your shotgun may result in serious injuries to you or others, and is NOT RECOMMENDED by the manufacturer. Any changes made to the shotgun or use of non-factory parts voids the factory warranty.

2) PROPER CARE AND STORAGE

Regular care and cleaning of your firearm is key to its proper functionality and reliability. ALWAYS make sure that the firearm is UNLOADED before you leave the range and check it again before you start the cleaning process.

THE RESPONSIBILITIES OF THE USER

The laws of your country give you the right to possess a hunting firearm. Appreciate and enjoy your rights with care. Be aware that, as an owner of a firearm, you are responsible for ensuring your own safety and that of your shooting partners, observers, and the environment.

DISCLAIMER

This firearm is sold with the understanding that the buyer will obey all applicable domestic laws, therefore Derya Arms is not responsible for death or injuries caused by incorrect or irresponsible use.

DERYA ARMS DOES NOT ACCEPT ANY RESPONSIBILITIES FOR DAMAGE DUE TO THE FOLLOWING CAUSES

1) INCORRECT OR IRRESPONSIBLE USE OF THE FIREARM
2) USE OF INCORRECT GAUGE AMMUNITION OR RELOADED, DAMAGED OR INPROPER CARTRIDGES
3) INSUFFICIENT AND/OR INCORRECT MAINTENANCE OR CLEANING WHICH CAUSES TO DAMAGE OR WEAR
4) SALE CONTRARY TO APPLICABLE LAWS AND REGULATIONS
5) CHANGING OR CONVERSION OF THE FIREARM'S ORIGINAL DESIGN, OPERATING MECHANISM, ACCESSORIES, MAGAZINES OR MECHANICALS
6) CARELESS, DANGEROUS OR CRIMINAL USE
7) USING THE FIREARM WITHOUT FIRST READING, UNDERSTANDING AND FOLLOWING ALL SAFETY RULES
8) ANY OTHER USE OR ACTION THAT IS BEYOND THE DIRECT CONTROL OF THE MANUFACTURER

IMPORTANT WARNING

1) Read the instructions booklet completely before using your firearm.
2) Always be aware of the handling and functional characteristics of your firearms.
3) Always unload your firearm when not in use (remove all cartridges).

When stored or not in use, firearms should always be unloaded and move the safety lever to the WHITE position to block the trigger of your firearm.

Always remove all cartridges and inspect the chamber to ensure your firearm is unloaded.
1) After shooting.
2) Before racking or after picking up the firearm.
3) Before putting the gun into its case.
4) Any time you are not using your firearm.
5) Before handing your gun to anyone else.
4) ALWAYS KEEP YOUR FIREARM POINTED IN A SAFE DIRECTION. This ensures you do not injure yourself or anyone else.
5) ALWAYS STORE YOUR FIREARM OUT OF REACH OF CHILDREN OR OTHER UNAUTHORIZED PEOPLE. There are many ways of keeping your firearms locked and stored safely and securely. Always secure your firearm in accordance with applicable laws in your area and always unload and then lock the firearm when not in use or whenever it will be unattended.

6) ALWAYS OBEY ALL LAWS REGARDING OWNERSHIP, TRANSPORT, AND SHOOTING YOUR FIREARM. Never point your firearm at a person. Do not harm any person or damage any public property.

7) IF YOUR FIREARM DOES NOT FIRE AFTER PULLING THE TRIGGER: STOP, WAIT A MINUTE, AND USE EXTRA CAUTION WHEN OPENING THE BOLT. If your firearm did not fire after pulling the trigger STOP! Keep the firearm pointed in a safe direction, apply the safety by moving the safety lever to the white position. Wait 60 seconds. Carefully open the bolt by pulling the cocking handle and eject the shell in a safe direction. Always remember when you experience a misfire, your firearm is still loaded and could fire at any time (a "hang fire").

8) ALWAYS TREAT YOUR FIREARM AS IF IT IS LOADED, EVEN WHEN THE SAFETY IS ON. Always keep your finger away from the trigger unless you are on target and prepared to shoot. Never forget that even with safety ON, you are responsible for the direction your firearm is pointing. Do not count on a mechanical device.

9) This firearm was produced under the control and supervision of Derya Arms. The firearm must never be altered. Derya does not recommended the use of any spare parts or accessories and magazines other than those included in the original box or received from Derya. If you need magazines, spare parts or repair, contact our authorized distributor in your country or Derya Arms ONLY.

10) ENSURE THE BARREL IS NOT PLUGGED OR OBSTRUCTED BEFORE YOU LOAD YOUR GUN. The barrel should not have any residue from bore cleaning solvent or oil, or any other foreign material inside the bore, chamber or choke. If the barrel is blocked or otherwise obstructed, even partially, this may cause bulging and/or a breech explosion and/or a split barrel. If you feel a strange recoil or the report sounds unusually loud or soft STOP SHOOTING IMMEDIATELY and check the barrel for obstructions and bulges.

NEVER try to clear an obstruction in your barrel by firing another shell!

ANY PARTIAL OR COMPLETE BORE OBSTRUCTION can cause serious injury or death to the shooter or bystanders.

SERIAL NUMBER

The serial number is engraved on the firearm on several places. Every firearm has a unique number. This number is used for legal and warranty matters. Derya suggests that owners note and store the serial numbers of all of your firearms in a secure location away from the firearms.

DISASSEMBLY OF THE FIREARM

1) Remove the forend by pulling the catch in arrow direction.

2) Attach barrel to receiver.





LOADING THE FIREARM

1) Break open the barrel by sliding the lever in arrow direction.

2) Insert proper cartridges in to the chamber.





S- Safe position.
O- Activates the upper barrel first. (Over)
U- Activates the upper barrel first. (Under)

The selectors position indicates the current chosen operation mode.

- If **"S"** is visible, the firearm is in **SAFE** position.
- If **"U"** is visible, the firearm will fire the cartridge in the **LOWER** barrel first.
- If **"O"** is visible, the cartridge in the **UPPER** barrel will be fired first.



BASIC PARTS


P.NO	PART NAME
1	Receiver
2	Receiver Pin
3	Hammer Plate
4	Cocking Lever
5	Cocking Lever Spring
6	Cocking Lever Pin
7	Locking Block
8	Top Lever
9	Top Lever Spring
10	Top Lever Spring Pin
11	Top Lever Screw
12	Injector Firing Pin Spring
13	Injector Firing Pin
14	Firing Pin Spring
15	Upper Firing Pin
16	Firing Pin Pin
17	Injector Firing Pin Spring
18	Injector Firing Pin
19	Firing Pin Spring
20	Lower Firing Pin
21	Firing Pin Pin
22	Cover Plate
23	Cover Plate Lock Spring
24	Cover Plate Lock
25	Cover Plate Lock Pin
26	Trigger Guard
27	Long Slotted Pin
28	Short Slotted Pin
29	Trigger
30	Transfer Block Spring
31	Transfer Block Spring Pin
32	Transfer Block
33	Transfer Block Pin

P.NO	PART NAME
34	Trigger Pin
35	Safety Spring
36	Safety
37	Safety Ball Spring
38	Safety Ball Spring
39	Safety Selector
40	Safety Selector Pin
41	Safety Washer
42	Safety Pin
43	Bottom Hammer
44	Hammer Washer
45	Top Hammer
46	Hammer Pin
47	Trigger Sear Catch
48	Trigger Sear Catch Spring Pin
49	Trigger Sear Catch Spring
50	Trigger Sear Catch
51	Trigger Sear Catch Spring Pin
52	Trigger Sear Catch Spring
53	Trigger Sear Catch Pin
54	Hammer Spring Guide Rod Pin
55	Hammer Spring
56	Right Hammer
57	Hammer Spring
58	Hammer Spring Pin Bushing
59	Hammer Spring Pin Washer
60	Hammer Spring Pin
61	Hammer Spring
62	Hammer Spring Pin Bushing
63	Hammer Spring Pin Washer
64	Barrel Assembly
65	Left Ejector
66	Ball

P.NO	PART NAME
67	Ball Pin
68	Ball Spring
69	Ejector Ball Pin
70	Ejector Spring
71	Right Ejector Locking
72	Right Ejector
73	Ball
74	Ejector Ball Pin
75	Ball Spring
76	Forend Lock Screw
77	Ejector Spring
78	Left Ejector Locking
79	Forend
80	Forend
81	Forend Plate
82	Forearm Bolt
83	Forend Latch
84	Forend Latch Button Spring
85	Forend Latch Button
86	Forend Plate Screw
87	Forend Screw
88	Stock
89	Stock Connection Washer
90	Stock Connection Screw
91	Recoil Pad
92	Mobile Choke
93	Recoil Pad Screw

Note:
Some models will vary from exploded view.

DERYA®


91
90
89
92
88
36
41
42
38
39
37
40
35
1
2
5
4
3
6
32
31
30
33
34
29
55
59
58
57
56
54
51
52
53
63
48
47
50
62
61
49
45
60
46
43
44
24
25
23
22
28
27
26
7
8
9
10
11
16
17
18
21
12
19
20
13
14
15
64
82
81
86
93
87
83
84
85
80
79
66
77
76
73
74
70
69
65
68
67
71
78
72
75

USAGE OF CHOKE TUBES

The choke is what controls the openness or tightness of the pattern of your shotgun. The chart below lists the choke available (from open to tight), and the corresponding marks that indicate the choke of your specific shotgun for guns with mobile choke tubes.

MARKING	USAGE OF CHOKE TUBES		NOTCHES
*	**FULL**	Suitable for longer ranges (DON'T USE SLUGS!)	
***	**MODIFIED**	Suitable for medium ranges (DON'T USE SLUGS!)	
*****	**CYLINDER**	Suitable for short ranges	

The threads of the choke tube and the internal threads of the barrel should be cleaned after each use and before installation of the tube.

To install a tube, insert the tube into the barrel and tighten with your fingers. Once the tube is finger-tightened, tighten with the appropriate choke-tube wrench until the tube in snug. DO NOT over tighten or forcefully tighten with wrench.

Warranty Certificate

Derya warranty covers its firearms and parts. We offer 2 years Warranty on our products for their intended purpose. As with any product, abuse, gunsmithing by an unqualified person and normal wear and tear are excluded. Additionally, if the firearm was modified and/or repaired by an unqualified gunsmith without permission from DERYA®, the warranty will be void.

DERYA® warrants that the enclosed firearm was originally manufactured free of defects in material, workmanship and mechanical function. DERYA® agrees to correct any defect in the firearm for the original purchaser/importer by repair, adjustment or replacement, at DERYA's® option, with the same or comparable quality components (or by replacing the firearms at DERYA's® option); provided, however, that the firearm is returned unloaded and the freight prepaid.

This warranty is null and void if the firearm has been misused, damaged (by accident or otherwise), fired with hand loaded, reloaded or improper shell, fired with an obstruction in the barrel, damaged through failure to provide reasonable and necessary maintenance as described in the manual accompanying the firearm, or if unauthorized repair or any alteration, including of a cosmetic nature, has been performed on the firearm.

Subject to the foregoing, this warranty confers the right to have the covered firearm or its parts repaired, adjusted or replaced exclusively upon the original purchaser, which right is not transferable to any other person. No implied warranties of any kind are made herein and this warranty does not apply to any accessory items attached or appurtenant to the firearm.

In no event shall DERYA® be liable for any incidental or consequential damages arising from or in connection with this warranty, In the event warranty service is needed, contact the dealer you purchased the firearm from; or the importer/distributor of your country; or DERYA® customer service by mailing to support@deryaarms.com.

12/2023

Derya Silah San.Ltd.
O.S.B. 41959 Sk.
No:24/1 42700
Konya/Turkey

+90 332 514 8118

support@deryaarms.com

www.deryaarms.com